

## VENTS & BREATHERS

[Vents and Breathers](#)- for relief of trapped moisture in roofing systems. Vents and Breathers are used to relieve moisture vapor trapped within a roofing system. Moisture may have entered the system due to drying of lightweight insulating concrete materials, leaks, faulty vapor retarders, or during construction. Portals Plus Vents and Breathers can prevent blistering, delamination, and billowing of the membrane, while helping to maintain thermal design efficiency. Vents are manufactured with a one-way valve which opens to relieve moisture vapor pressure and then closes to prevent moisture from re-entering the system. Breathers allow for both exhaust as well as convective movement of air within the system.

How many do I need? [See the Vents and Breathers Recommendations](#)

<b>ALUMINUM</b>		QTY/ CTN	LIST PRICE PER UNIT
NEW UPC PART NUMBER	DESCRIPTION		
<a href="#">71008</a>	ALUMINUM BREATHER (std.)(2-WAY)	25	
<a href="#">71028</a>	ALUMINUM VENT (std.)(1-WAY)	25	
73008	INSULATION INSERT (for standard only)	25	



Call Customer Service For Price